

# PROJECT NOMAD CONNECTION GUIDE

[WeHaveNomad.com](http://WeHaveNomad.com)

**Start here:** Plug in Project NOMAD, press the power button, and wait 2-5 minutes.

**Internet is never required.**

1

## DIRECT KIOSK

**Use when:** A monitor, keyboard, and mouse are connected directly to the unit.

### Steps

- Connect the monitor, keyboard, and mouse.
- Power on Project NOMAD.
- Wait 2-5 minutes for the NOMAD screen to open automatically.

2

## HOME / LOCAL NETWORK

**Use when:** Project NOMAD and your phone, tablet, or computer are on the same home or local network.

### Steps

- Connect Project NOMAD to your home or local network.
- Connect your phone, tablet, or computer to that same network.
- Open a browser and enter one of the addresses below.

[nomad.local:8080](http://nomad.local:8080) or [nomad:8080](http://nomad:8080)

3

## OFFLINE HOTSPOT

**Use when:** No home network or internet is available.

### Steps

- Open Wi-Fi settings on your phone, tablet, or computer.
- Connect to Wi-Fi: NOMAD connect and open 10.9.8.7
- Wi-Fi password: nomadata or the password printed with the unit.
- Open a browser and enter the address below.

[10.9.8.7](http://10.9.8.7)

## TROUBLE-SHOOTING

- Wait a full 5 minutes, then refresh the page.
- Make sure your phone, tablet, or computer is connected to NOMAD Wi-Fi or the same local network.
- Power off the unit, wait 10 seconds, power it back on, then wait 2-5 minutes.

**Need help?** [wehavenomad.com/contact](http://wehavenomad.com/contact)